


- ## GENERAL NOTES!

1. FINISH INSIDE ~ REMOVE ALL DIRT, GREASE, SLAG & WELD SPATTER.
2. FINISH OUTSIDE ~ (STAINLESS STEEL) ~ SAME AS NOTE #1. ~ (CARBON STEEL) ~
SANDBLAST & PAINT "1" ONE COAT CARBOLINE "CARBO ZINC "11"
TO A DRY FILM THICKNESS OF 2.5 MIL MINIMUM PER
HERCULES STD. 11G5-G61, & 5C5-3E1 Pg. 5 PART 7.2
3. HOLD HYDRO TEST FOR A MIN. OF 2 HOURS.
4. AIR TEST TUBE BUNDLE @ 10 P.S.I. AFTER HYDRO. TEST.
5. FURN. ONE SPARE SET OF GASKETS.
6. PAINT THE EQUIPMENT N° ON VESSEL IN LETTERS @ LEAST 3" HIGH.
7. PROTECT ALL EXPOSED FLG. FACES ~ w/ MAXWITE COVERS FOR SHIPMENT.
8. COAT EXT. BOLTING "1" AN APPROVED LUBRICANT COMPATIBLE TO THE BOLTING
MAT'L.

P.O. # 026-57570

EQUIP. # E-206-3A

[illegible]

104 047